

Smart Film Cable Exit Direction Selector — Left, Right, Top, or Bottom

- Configurable cable exit at left, right, top, or bottom of film panel
- Selection made prior to fabrication of the smart film assembly
- Aligns power lead routing with surrounding framing or conduit layout
- Applies to switchable smart film installations

OVERVIEW

The Smart Film Cable Exit Direction Selector is a configuration option for switchable smart film installations, allowing the cable exit point to be specified as left, right, top, or bottom relative to the film panel. This selection determines how the power lead routes out of the film assembly, enabling installers to align the cable path with the surrounding architecture, framing, or conduit layout before fabrication.

APPLICATIONS

- Switchable smart glass partitions
- Smart film window retrofits
- Conference room privacy panels
- Architectural glazing installations

PROVENANCE — REVIEW COPY ONLY

slug	value	source	confidence

Specifications subject to change without notice.